

Timesegment Limited www.railwaysignalcompany.com

Welcome to this the latest edition of the mechanical signalling catalogue. This listing shows the parts awarded PADS numbers by Network Rail and are listed in PADS order. For Parts which currently do not have PADS certification, and for general ordering information see the main catalogue.

PADS No.	Drawing No.	Description Listed in Pads Order
62/050062	411 MB9192/3	Operating Lever Clipping Up Switch Unit ATC
62/050068	470 MA 9108/11	Arm Indicating ' Not In Use' formerly S 373
62/050070	S372 MB 8482 MB 9108/7	Cut-out Switch Box ATC
62/050071	472 MB 8309 MB 9108/5	Elbow Cut out was S374 ATC
62/050072	S 229 MD 5824/6 MA 9108/21	Valve Guide ATC
62/070110	V180*c MB 3987/133	End Bracket Facing
62/070111	V230 MD 8608	A.T.C. Ramp Facing End Bracket
62/070112	V231 MD 8609	A.T.C. Ramp Trailing End Bracket
62/070113	V232 MD 8711	A.T.C. Ramp Centre Bracket
62/070114	V182 MB 3987/135	Ramp Bracket No. 2 1 Hole (Intermediate)
62/070115	V183	Ramp Bracket Trailing Piece
86/068852	Reading BRS-SM 452/5	Lever Clip Box Ground Frame A31395
86/075151	P161 BRS-SM 315/2	F.P.L Detector Slide Mk II
86/075355	P162 BRS-SM 315/4	Cover For Mk II see Aluminium Section Cover
86/075531	P160 BRS-SM 315/1	F.P.L Plunger Base Mk II
86/077760	810	Lamp Ring 9"
88/003133	74	Connection Contact Box - Old pattern
88/003134	74 MB 5076/130	Connection Contact Box - New pattern
88/011072	58	Gate Hinge Bearing Large New Pattern
	& 3	
88/023006	8	Fasteners Lineside Cupboard Left hand formerly S 506
88/023007	8	Fasteners Lineside Cupboard Right hand formerly S 507
88/023011	V224*	Duct Entry Pipe?
88/023013	V35	Crank Pedestal Cap see section K
88/023095	V6 MB 5573/3	Lever Contact Base
88/023118	12	Contact Box Strip
88/023125	V36 MD 5834/7	Contact Box Base 4 way
88/023127	V38 MD 5834/6	Contact Box Base 6 way
88/023129	V44 MD 5834/5	Contact Box Base 8 way
88/023152	V223	Fouling Bar Rotary Type Cover see section Q
88/023156	11	Fastener Nut Rotary Fouling Bar (Weight Bar)
88/023393	839	Strip Handle Lug
88/023395	879	Wedges for Lamps Strip 12" x 1 ¾

PADS No.		Drawing No.	Description Listed in Pads Order
88/023398	13		Boss Slot Box
88/023621	V163		Cable Protector No. 1
88/023622	V164		Cable Protector No. 2
88/023685	V225		Cable Hook 1 way
88/023686	V226	MB 7218	Cable Hook 2 way
88/023687	V227	MB 7219	Cable Hook 3 way
88/026498	T227	MD 8248/7b	Base Lifting Barrier Control Pedestal.
88/026500	348		Electric Lock Plunger Bracket.
88/026501	349	MA 6494/5	Electric Lock Bridge Piece
88/026503	1005		Token carrier Bracket
88/026507	1010NA		Token Key Pocket.
88/026637	344	MA 6488/7	Electric lock Base Mk1 Contact Plunger was S 557
88/062416	X10		Gear Wheel Bush
88/074413	X171		Letter Plate "A
88/074414	X172		Letter Plate "B
88/074415	X173		Letter Plate "N
88/074416	X174		S&T Cable Indication Plate with Arrow Two versions available
88/074417	X179	MA 7843/0	Number Plate "0
88/074418	X180	MA 7843/1	Number Plate "1
88/074419	X181	MA 7843/2	Number Plate "2
88/074420	X182	MA 7843/3	Number Plate "3
88/074421	X183	MA 7843/4	Number Plate "4
88/074423	X185	MA 7843/6	Number Plate "6
88/074425	X187	MA 7843/8	Number Plate "8
88/074426	X188	MA 7843/9	Number Plate "9" order X185 (its the same)
88/074427	X176	MA 7843/12	Letter Plate "J
88/074428	X177	MA 7843/13	Letter Plate "S
88/074429	X178	MA 7843/14	Letter Plate "Q
88/074431	X175		Letter Plate "K
88/074432	X189	MA 7843/19	Letter Plate "C'
88/074434	X190		Letter Plate "D
88/074435	X193		Letter Plate "E
88/074583	E61	MA 8428/15	Blade Single Dummy BR Signal Detector
88/074584	E59		Box Detector Old Pattern
88/074589	E60	BRS-SM101A	Box Detector New Pattern
88/075357	P154		F.P.L Detector Bolt Lock New Pattern
88/079896	429	MA 8945	Hinge C.L. Signal Formerly 430B
88/079897	430	MA 8946	Hinge C.L. Signal Formerly 430A
88/079919	432	5677/1	Rose Fastener C.L. Signal
88/079982	431	MA 8948	Fastener Spindle C.L. Signal
88/080001	84	MA 7895/7	Token Crossing Contact Bracket was S 66
88/080002	87		Front Bearing Plate 1948 Block Instrument was S522
88/080557	85		Reminder Flap 1948 Block Instrument was S520
88/080569	86		Locking Lever 1948 Block Instrument was S 523

PADS No.		Drawing No.	Description Listed in Pads Order
88/080580	88		Back Bearing Plate 1948 Block Instrument was S523
88/080616	520	MA 9197	Arm Bracket Emergency release plunger
88/080618	521		Bridge Emergency Release Plunger
88/082905	345	MD 6494/3	Electric lock Base Mk1 was S 345
88/082939	347		Armature for Electric Lock similar 351
88/082946	346		Eyelet for Electric Locks was 645
88/082951	194		Drive Joint Electric Lock
88/082954	353	MB 8153/3	Armature Electric Lock N.P.
88/083002	X23		Bracket Intermediate Token Instrument
88/083005	X40		Compensator Base see Section L
88/083006	X43		Independent Disc Arm
88/083007	X44		Front Token Instrument
88/083010	X46		Base Token Instrument
88/083012	X47		Blast Pipe for Small Black Smiths Forge
88/083015	X57	MB 8652	Derailment Bars 5'0" Long
88/083039	X59		Stop Tap Surround
88/083044	X60		Stop Tap Lid
88/083046	X63		Derailment Bar Bracket
88/083048	X64		Lever Frame Cam Box similar B21
88/083050	X72		Duct Taper Joint Duct Taper Joint
88/083051	X74		Independent Disc Spectacle as X43 but for use with Straight edge glass
88/083054	X85		Spacer Level crossing Gate Post Base?
88/083055	X100*c		Signal Plate Large, 6 levers
88/083056	X110		Lever Frame Quadrant 4" Centre Converts Class 6 Frame from 5" or 5¼" to 4
88/083057	X111*		Telephone and Battery Cupboard Weight
88/083059	X112?		
88/083066	X115		Lever Clip Box (Saxby and Farmer)
88/083067	X116		Gate Latch Stop R.H. see Section T
88/083072	X117		Gate Latch Stop L.H.
88/083075	X133		Bridge Piece? possibly U155 Floor Fastener
88/083079	X134		Pole Base Dia 5½ Dia possibly for early colour light signals on gantries
88/083080	X143		Drip Loop Lid
88/083081	X144		Drip Loop Base
88/083082	X152		Signal Pole Lever Plate For 4 Levers
88/083085	X153		? Large Right Angle Thing
88/083094	X155		Tubular Pole Top?
88/083095	X158		Special Lever Quadrant (possibly Mckenzie)
88/083097	X160		? Bracket Fits on to rail with a vertical bearing
88/083098	X164		25" Off-Set Bracket For 5 ½" O.D. Pole
88/083099	X167		Clip Block for 5 ½" & 6 ½" -Former Male
88/083100	X168		Clip Block for 5 ½" & 6 ½" -Former Female
88/083184	334	MA 8325	Small Ring Assembly (Webb & Thompson) Staff includes sleeve also 383

PADS No.		Drawing No.	Description Listed in Pads Order
88/083185	336		Small Rings (Webb & Thompson) Staff
88/083186	337		Shoe Switch Type A Base ATC
88/083187	338		Shoe Switch Type A Bracket ATC
88/083194	339		Shoe Switch Type A Lever ATC
88/083198	340		Flat Bar 7" x 1 1/8" x 1/4"
88/083199	341		Round Bar 8" x 1/2"
88/083239	X45		Back Token Instrument
88/083397	246		Bezel Occupation Instrument
88/083398	254	MA 9569/12	Key Boss N.P. G.F. Release Instrument
88/083400	236		Commutator Shaft Occupation Instrument
88/083401	248	MA 9569/47	Guide Block Occupation Instrument
88/083408	247	MB 9569/18	Armature Lever Occupation Instrument
88/083409	250	MB 9569/15	Commutator Spindle N.P. G.F. Release Instrument
88/083412	238	MA 10149/21	Locking Pawl Occupation Instrument formerly S 391
88/083413	V145	MD 7223	Occupation Key Box Back
88/083414	V146	MB 7224	Occupation Key Box Base
88/083415	V144A	MD 7234	Occupation Key Box Front
88/083416	V147	MB 7225	Occupation Key Box Bridge Plate
88/083417	306		Bearing Plate G.F Control Instrument small was S496
88/083418	449		Plunger Ground Frame Control Instrument
88/083419	237		Key Boss Occupation Instrument
88/083420	303		Coil Bracket G.F Control Instrument small was S493
88/083421	305		Bridge G.F Control Instrument small was S495
88/083422	304		Disc G.F Control Instrument small was S494
88/083423	301		Front G.F Control Instrument small was S491
88/083424	302		Bracket for Coil G.F Control Instrument small was S492
88/083426	453		Resetting Bracket G.F. Control Instrument was S501
88/083427	239		Bezel G.F. Release Instrument formerly S 392
88/083440	X22		Base Intermediate Token Instrument
88/083478	29		Commutator Segment was S92
88/083479	30		Commutator Segment was S93
88/083480	31		Commutator Segment was S94
88/083481	32		Commutator Segment was S95
88/083482	33		Commutator Segment was S96
88/083483	34		Commutator Segment was S97
88/083484	35		Commutator Segment was S98
88/083485	36		Hinge Piece 10" Token Instrument
88/083637	1020		Token Key
88/083656	V216		Staff Angle Bracket
88/083658	J10		Staff/Token Setting Down Frame Net Clips
88/083661	J11		Staff/Token Net and Frame Clip Front Plate Se
88/083671	335	MA 8327	Large Rings (Webb & Thompson) Staff

PADS No.		Drawing No.	Description Listed in Pads Order
88/085003	X191		? Handle
88/085004	X192		? Cam similar Webb & Thompson Inst.
88/085005	X194		Long Arm
88/085006	X195		Corner Piece?
88/085007	X196		Cam
88/085008	Z1	MD 7062	Plate Stay Small Currently not available
88/085010	Z2	MD 7061	Plate Stay Large Currently not available
88/085011	P162		Cover Facing Point Lock Mk11
88/085012	1021		Stencil Speed Lamp 5 m.p.h
88/085013	1022		Stencil Speed Lamp 10 m.p.h
88/085014	1023		Stencil Speed Lamp 15 m.p.h
88/085015	1024		Stencil Speed Lamp 20 m.p.h
88/085017	1025		Stencil Speed Lamp 25 m.p.h
88/085018	1026		Stencil Speed Lamp 30 m.p.h
88/085019	1028		Stencil Speed Lamp 35 m.p.h
88/085020	1027		Stencil Speed Lamp 40 m.p.h
88/085021	1008		Tablet Pocket 4
88/085022	1009		Tablet Pocket 4¼
88/085023	1029		Plate C Lamp
88/085024	1030		Plate T Lamp
88/085025	2		Angles for Spectacles
88/085026	4		Resetter Arm Intermediate Token Instrument
88/085027	5		Lock Guide Intermediate Token Instrument
88/085028	15		Bridges Commutator
88/085029	19		Bracket Small
88/085030	20		Spring Bracket Electric Lock
88/085031	21		Base Galvanometer
88/085032	22		Bezel Galvanometer
88/085033	23		Key Boss Occupation Box
88/085034	24		Ringin Key Bracket
88/085035	25		Coil End (ATC) was 640
88/085036	26		Ringin Key Strip 8" x 7/8" x ½ was S101
88/085037	27		Double Flange Roller for use with V5 to make U43
88/085039	116		Handle Platform Switch was S116
88/085040	117		Base Platform Switch was S117
88/085041	118		Bracket Spring Platform Switch was S118
88/085042	120		Key Triangular Socket Section
88/085043	129		End Token Carrier???
88/085050	131		End Large Staff
88/085051	134		Contact Plate Lamp Expander
88/085054	135		Contact Bar Lamp Expander
88/085056	141		Frame Bracket Double Electric Lock
88/085057	142		Guide Electric Lock
88/085058	143		Bridge piece Shoe Switch (ATC?)
88/085059	144		Spring Block
88/085060	146		Tab No 1 Speed No. Plate

PADS No.	Drawing No.	Description Listed in Pads Order
88/085061	147	Tab No 2 Speed No. Plate
88/085062	149	Tab No 3 Speed No. Plate
88/085064	150	Tab No 4 Speed No. Plate
88/085065	151	Tab No 5 Speed No. Plate
88/085067		Tab No 6 Speed No. Plate
88/085069		Tab No 7 Speed No. Plate
88/085070		Tab No 8 Speed No. Plate
88/085071		Tab No 9 Speed No. Plate
88/085072		Tab No 0 Speed No. Plate
88/085075	172 MA 6630/2A	Locking Nib Mckenzie Type 9 Frame M.2
88/085076	173	Locking Nib Mckenzie Type 9 Frame M.3
88/085079	174 MA 6632/24	Locking Nib Mckenzie Type 9 Frame M.4
88/085080	175	Locking Nib Mckenzie Type 9 Frame M.5
88/085081	176 MA 6634/2	Locking Nib Mckenzie Type 9 Frame M.6
88/085082	177	Locking Nib Mckenzie Type 9 Frame M.7
88/085083	178	Locking Nib Mckenzie Type 9 Frame M.8
88/085084	179	Locking Nib Mckenzie Type 9 Frame M.9
88/085085	180 MA 6638/2	Locking Nib Mckenzie Type 9 Frame M.10
88/085086	181	Locking Nib Mckenzie Type 9 Frame M.11
88/085087	182	Locking Nib Mckenzie Type 9 Frame M.12
88/085088	188	Blade Joint 5 ¼" Stud Locking Frame
88/085089	192	Special Joint 5 ¼" Locking Frame
88/085090	203	Locking Frame Lug Joint Hinge Centre 3" Blade
88/085091	211	Key for Quadrant on Signal Post
88/085092	217	Knob Morse Ringing Key
88/085093	226 MA 9108/19	Valve Spindle ATC
88/085094	233	Tapper Lever Disc (Block Instrument)
88/085095	242	Link L.F. Cam Box N.P.
88/085096	333	Resetter Bracket Electric Lock
88/085097	334	Ring 6" Dia 4 ¾" hole 1 1/8" Deep
88/085098	350L	Tapper Sides Disc Instrument (Old Style Block Inst)
88/085099	351 MB 8153/3	Lever Armature Electric Lock
88/085100	354	Gate Lamp Socket
88/085101	357	Hinge IBS Cupboard was S 531
88/085102	358	Hinge Staple IBS Cupboard was S532
88/085103	359 MA 7838/3	Shoe Switch Lever Type A diesel Loco ATC
88/085104	363	Shoe Switch Blade Contact Box
88/085105	364	Strip 5" x 7/8" x 3/8" Cuts 4
88/085106	370	Strip 12" x 1 ¾" x 7/8"
88/085107	375 MA 7950	Strip 7" x 1" x ¼"
88/085108	376C	Strip 8" x 1 1/8" x 3/16"
88/085109	381?	Similar to 520 ?
88/085111	382 MA 9569/52	Spring Block Occupation Instrument
88/085113	383	Sleeve Electric Train Staff (Webb & Thompson)
88/085116	385	Strip Triangle Occupation Instrument

PADS No.	Drawing No.	Description Listed in Pads Order
88/085117	386	Valve Bracket
88/085118	388?	Staff Name End
88/085120	408	Base Arm Gauge
88/085121	409	MA 8919
		Bell Pillar (Universal Type)
88/085122	415	Locking Frame Nib RH
88/085123	423	Washer Large Signal Arm
88/085124	424	MA 8300
		Washer Small Bracket Signal Structure
88/085125	446	MB 8116
		Armature Coil Bracket ATC
88/085126	447	Spring Bracket ATC
88/085127	448	Terminal Brackets Parapole ATC
88/085128	452	Case Parapole ATC
88/085129	454	Armature Strip G.F. Control Instrument was S509
88/085130	456	MB 8086/2
		Cover C patt also 541 ATC
88/085131	462	MB 8062/20
		Armature Lever also MB 8086 ATC
88/085132	466	Siren Nut ATC
88/085133	468	Relay Contact Piece ATC
88/085134	473	Channel Strip
88/085135	476	MA 8146/5
		Siren Valve ATC
88/085136	480	Cut out Valve Plunger ATC
88/085137	481	MA 5469
		Ventilator Cover was S527
88/085138	501	Channel Bridge
88/085139	506	Corner Diagram Frame
88/085140	507	Angle Bar 8 ¼" x 1 ½" x 1" x
88/085141	537	MA 8086/8
		Resetting handle ATC also 460
88/085143	540	MB 8011
		Relay Box ATC also 444
88/085144	542	Relay Plate, step
88/085145	544	ME 8086/3
		Case C pattern ATC also 451
88/085146	545	ME 8091
		Box cut out ATC also 478
88/085147	546	MH 8098
		Bush cut out ATC also 479
88/085148	547	MA 8056
		Bell Plate Strip ATC also 471
88/085149	548	MB 8052
		Bell Case ATC also 450
88/085150	549	MB 8054
		Bell Case Cover ATC also 455
88/085151	550	MA 8029
		Pivot plate ATC also 786
88/085153	551	MA 8102
		Coil Ends S.P.L Bottom ATC also 445
88/085155	552	MB 8146/3
		Body Siren Cab App. ATC
88/085156	558	Bush Roller Switch (Block Switch)
88/085157	567	Relay base, lamp
88/085159	617A	Bracket Electric Lock
88/085160	622	Cover Sliding Contact
88/085161	624	Clip for Signal Secs
88/085163	634	Lamp Ear
88/085164	673	Bar Handle Medium Switch (Block Switch)
88/085165	699	Bracket Key Tapper - Strip
88/085167	702	Label Lever No. 3
88/085168	705	Label Lever No. 6
88/085169	706	Label Lever No. 7

PADS No.	Drawing No.	Description Listed in Pads Order
88/085170	709	Label Lever No. 10
88/085171	710	Label Lever No. 11
88/085173	713	Label Lever No. 14
88/085174	714	Label Lever No. 15
88/085175	715	Label Lever No. 16
88/085177	728	Label Lever Large Oval Flange
88/085178	748	Nut Fork large
88/085179	750	Nut Bell Stand
88/085180	752	Nut Bell Cap
88/085181	787	Pivot Plate Relay Small ATC
88/085182	788	Pivot Plate Relay Small Double contact ATC
88/085184	789	Plate AC Relay
88/085185	790	Switch Base also Tapper Block Bell Coil Base
88/085186	792	Relay Plate Selective
88/085187	819	Screws Bell Stand
88/085188	820	Screws Case Small
88/085189	821	Base Polarised Relay was S475
88/085190	825	Screws Fork Large
88/085191	833	Channel Strip
88/085192	884	Knobs Indicator
88/085193	885	Trip Indicator Repeater
88/085194	S29	Blade Guide
88/085195	S30	Bearing Bracket
88/085196	S45	Bush Control
88/085197	S59	See 385
88/085198	S74	Front Plate Roller Switch (Block Switch in-out)
88/085199	S77	See 382
88/085201	S110	Dowel Strip
88/085202	S115	Sleeve Nut
88/085203	S116	Lock Nut
88/085204	S140	Plates Cam ?
88/085205	S193	Ring 1 1/8"
88/085207	S197	Lamp Bezels (Small Lens as in ground disc lamp)
88/085208	S200	Relay Base
88/085209	S201	Relay Sides
88/085210	S202	Channel Strip
88/085211	S226	Valve Spindle see 226 ATC
88/085212	S268	Ring 3/4"
88/085213	S273	Large "O" Siding Signal Arm
88/085214	S274	See 56
88/085219	S308	Base Plate Bristol Type Block Instrument
88/085220	S310	Back Plate Bristol Type Block Instrument
88/085221	S311	Bridge Bristol Type Block Instrument
88/085223	S312	Locking Disc Bristol Type Block Instrument
88/085224	S313	Quadrant Bracket Bristol Type Block Instrument
88/085225	S314	Resetting Lever ATC

PADS No.	Drawing No.	Description Listed in Pads Order	
88/085226	S315	Bearing Bush ATC	
88/085227	S316	Handle Bush ATC	
88/085228	S317	Round Bar 2 1/8" dia x 9"	
88/085229	S320	Knuckle joint Tappet	
88/085230	S343	Connection Box ATC	
88/085231	S345	Resetting Lever ATC	
88/085232	S349	Disc (Not in use) ATC	
88/085233	S350	Plate (close only when atc out of order) ATC	
88/085234	S366A	Bracket A L type ATC	
88/085235	S366B	Bracket B R type ATC	
88/085236	S371	MD 8484 MD 9108/3	Cut-out valve body ATC
88/085237	S388		Nameplate with Lug L.N.W.R pattern E.T.S
88/085238	S393	Bar Round 2 1/2"x 7"	
88/085239	S397	?	
88/085239	S398	Case Point Indicator	
88/085240	S399	Back Plate Point Indicator	
88/085241	S400	Front Plate Point Indicator	
88/085242	S401	Base Plate Point Indicator	
88/085243	S402	Locking Nib B	
88/085244	S409	Token End for use on one engine in steam Staffs etc	
88/085245	S417	Strip 8" x 1 1/2" x 1/4"	
88/085246	S419	Locking Nib B see also S402	
88/085247	S424	Detector Gauge Drop Piece	
88/085248	S425	Handle Roller Switch	
88/085249	S426	Bush	
88/085250	S428	Locking nib I	
88/085251	S432	Switch Lever	
88/085252	S433	Tapper Key	
88/085253	S434	Side Piece	
88/085255	S435	Armature Lever	
88/085256	S436	Angle Strip (contacts)	
88/085257	S437	Ring	
88/085258	S439	Receiver Hook (telephone rest hook)	
88/085259	S443	Re-setter Valve ATC	
88/085261	S447	MA 8966	Ring
88/085262	S450		Pivot Plate Large
88/085263	S451	Transit Contact Bridge	
88/085264	S452	Transit Contact Cover	
88/085265	S453	Transit Contact Cover	
88/085266	S454	Sender Magnet Case	
88/085267	S455	Sender Magnet Bridge	
88/085268	S458	Shutter	
88/085269	S459	Forked Bend	
88/085270	S460	Plates for Forked Bend	

PADS No.	Drawing No.	Description Listed in Pads Order
88/085271	S461	Carrier Sending Cap
88/085272	S476	Switch Slides ATC
88/085273	S478	Contact Makers ATC
88/085274	S479	Contact Holders ATC
88/085275	S482	Lever Receiver Tunnel Telephone
88/085276	S483	Hooks Tunnel Telephone
88/085277	S484	Connection Strip 3 Tunnel Telephone
88/085278	S485	Connection Strip 2 Tunnel Telephone
88/085279	S486	Connection Strip 8 Tunnel Telephone
88/085280	S487	Connection Strip Tunnel Telephone
88/085282	S488	Connection Strip 4 Tunnel Telephone
88/085283	S489	Connection Strip 3 Tunnel Telephone
88/085284	S490	Cup Siren Spinner ATC
88/085285	S497	Tapper Tapper Bell
88/085286	S498	Loop Hand Com
88/085289	S503	Case Relay ATC
88/085290	S504	Table Relay (Base)
88/085293	S505	Point motor cover
88/085294	S507	Bush
88/085295	S508	Washer
88/085296	S518	Supporting Bracket Left Hand
88/085297	S518	Supporting Bracket Right Hand
88/085298	S519	Motor Inspection Cover Large
88/085299	S524	Motor Inspection Cover Small
88/085300	S526	Block 7" x 6 1/2" x 3 1/4"
88/085302	S529	Escapement Crank (point motor ?)
88/085303	S530	Cap?
88/085304	S533	There are 6 Nibs 533 to 538 we have 5 of the 6 but only two are numbered
88/085305	S535	Locking Frame Nib
88/085306	S538	Locking Frame Nib
88/085307	S541	Rail Connection Base
88/085308	S555	Channel Strip
88/085309	S557	See 344
88/085310	S558	Fulcrum Bearing
88/085311	S559	Frame
88/085312	S560	Frame
88/085313	S561	Wing Nut/ Wing Bolt
88/085314	S562	Siren Air Vent ATC
88/085314	S564	MA 8783 Nut for Four cutter Machine
88/085315	S567	P.B. Bearing with wings 1 half plain
88/085316	X9	Strip
88/085317	262/16	Church 4 1/2"
88/085319	262/19	Flat 5"
88/085321	262/26	Round
88/085322	262/29	Sheep

PADS No.		Drawing No.	Description Listed in Pads Order
88/085323		MD 37295/1	Base Economical facing point lock
88/085324		MD 37295/3,4	Link Economical facing point lock
88/085325		MD 37295/5	Link Economical facing point lock
88/085326		MD 37295/	Link Economical facing point lock
88/085327		MD 336	Spectacle Plate
88/085328		MD 35148	Back Blinder
88/085329	Reading	49YS540*c	Fixture Tubular Signal
88/085330	Reading	50YS62*c	Ground Disc part of assembly to YS383004
88/085336	352	MD 7856A	Electric Lock Base Old pattern
88/085338	538	MA 8086/6	Resetting Lever ATC also 463
88/085338	539	MA 8086/14	Hinge Piece ATC also 469
88/085339	687		Lamp Hinge Top
88/085341	507		Angle Bar 8 ¼" x 1 ½" x 1 ¼" x 5/16
88/085341	507		Angle Bar 9" x 1 ½" x 1 ½" x ¼
88/085349			Adjusting Connection order as GM 300
88/091007	G178		Rod Guide No.2
88/091010			As above Lamp Bracket Only
88/091011	G193		Tubular Signal Blocks
88/091012	G197		Arm Stop C,S & W
88/091016	G233		Blinker Upper Quadrant
88/091017	G234		Boss and Spectacle Plate U.Q. LMS Style can be cast to take GWR arms
88/091018	G235		Boss and Spectacle plate GW style Upper Quadrant (Oxford Type)
88/091019	G236		Lamp Bracket Tubular Signal
88/091024	G237		Spindle Bearing Tubular Signal
88/091025	G238		Lamp Bracket Clips B.S. U.Q. Signal
88/091026	G239*c		Base for 6½" Tubular Mast
88/091027	G240*c		Base for 5½" Tubular Mast
88/091028	G242		Rear Cover Colour Light Signal?
88/091029	G242		Lever Plate 7 Levers
88/091031	G246	MB 6569	Strut Bracket Bottom 30' Angle
88/091032	G248		Channel Support Block Standard Bracket Signal
88/091040	T204		Base Small Half Round for Gate Post
88/091042	T55*c		
88/091044	T56	MD 5706/5	Gate Post Base Large
88/091046	G249		Channel Support Block Standard Bracket Signal
88/091046	T48		Square Base for Gate Post
88/091060	52	MB 6657/3	Gate Hinge Bearing Bottom Medium Old Pattern
88/091061	53	MB 6657/3	Gate Hinge Bearing Top Medium Old Pattern
88/091063	56		Gate Hinge Bearing Large Old Pattern
	& 4		
88/091066	59	MB 6638/3	Gate Hinge Bearing Small New Pattern
88/091069	50	MB 6656/3	Gate Hinge Bearing Bottom Medium New Pattern
88/091070	51	MB 6656/3	Gate Hinge Bearing Top Medium New Pattern
88/091089	T20	ME 6720/3	Gate Roller Box
88/091091	T9		Gate Shield Bracket Medium

PADS No.		Drawing No.	Description Listed in Pads Order
88/091096	T128	MB 6756/3	Revolving Lamp Bracket Bridge NB T182 In BR Catalogue
88/091098	T164*c	MA 8749	Cap Gate Post 10
88/091102	T203		Cap Shutting Post
88/091103			Hand Lever Clip See GM 76 Lever Frame
88/091103	76	MA 6050/7	Hand Lever Clips
88/091110	70		Adjusting Connection 1 3/8
88/091112	T3		Gate Dirt Cover 2 3/4
88/091114	T2		Gate Dirt Cover 2 1/4
88/091116	T1		Gate Dirt Cover 3
88/091118	T216*c	MD 5706/42	Road Stop Cover Large L.H.
88/091120	G250		Channel Support Block Standard Bracket Signal
88/091128	T43	MA 5706/27	Gate Spindle Cup Large
88/091136	T195		Cover Plate Frame Large.
88/091137	T40	MB 5706/25	Gate Quadrant Flange 2 1/4" Spindle
88/091139	T39	MB 5706/25	Gate Quadrant Flange 2 1/2" Spindle
88/091141	T38	MB 5706/25	Gate Quadrant Flange
88/091147	T118*c	MB 6609/5	Bottom Gate Hinge Small
88/091148	T120		Bottom Gate Hinge 2 1/4" Spindle
88/091150	T205		Hinge Wicket Gate, L.H
88/091151	T206		Hinge Wicket Gate, R.H
88/091152	T207		Hinge Wicket Gate, Central
88/091153	T119	MB 6609/5	Top Gate Hinge Small
88/091154	T121		Top Gate Hinge Medium 2 1/4" Spindle
88/091155	T117*c	MB 6607/5	Top Gate Hinge Large
88/091157	T161	MB 6829	Gate Hinge Bottom
88/091158	T169		Wicket Gate Hinge L.H. Old Pattern
88/091186	T149	MB 7235	Gate Latch Handle Left Hand
88/091188	T150	MB 8517	Gate Latch Handle Right Hand
88/091192	T146		Gate Latch Stop L.H.
88/091194	T145		Gate Latch Stop R.H.
88/091199	T138*	MB 7039	Gate Lock Bottom Gate
88/091201	T8		Gate Shield Bracket Large
88/091216	T210		Gate Lock
88/091221	T211		Gate Lock Nib
88/091224	T137*		Gate Lock Cover
88/091230	322		Pinion Gate Wheel 1 1/2" Pitch 2" Wide
88/091231	T104	MD 6698/3	Gate Crank Pedestal
88/091233	T100	MD 7077/3	Gate Crank Plate Large
88/091240	T155	MB 7244	Lock Crank Plate
88/091247	T34	MB 5706/12	Small Gate Post Half Round Flange
88/091249	T33	MB 5706/11	Medium Gate Post Half Round Flange
88/091253	T202	MB 5706/13	Shutting Post N.P.
88/091258	T190	MB 6650/13	Lever Frame Quadrant also Detonator Placer Frame
88/091259	T46	MB 6682	Gate Quadrant Rack

PADS No.		Drawing No.	Description Listed in Pads Order
88/091269	T26		Gate Rollers Friction
88/091273	T110		Gate Shoe Long Right Hand New Pattern
88/091274	T111		Gate Shoe Long Left Hand New Pattern
88/091278	T181	MB 6650/3	Gate Lever Side L.H. also Detonator Placer Frame
88/091279	T180	MB 6650/3	Gate Lever Side R.H. also Detonator Placer Frame
88/091288	T106		Gate Crank Spindle
88/091289	355		Stand Gate Lamp
88/091291	T212	MD 6589/9	Gate Step Bracket 9
88/091293	T213		Gate Roller Bracket
88/091295	T214	MA 6589/12A	Gate Spindle Cup N.P.
88/091299	T215		Gate Roller New Pattern
88/091311	T64		Gate Stop Roller Box
88/091313	T218		Tumbler Box Post Mounted Gate Stop
88/091318	T10		Gate Shield Bracket Small
88/091337	T52	MB 6772/4	Gate Stop Sides Road and Line Stop
88/091350	T22		Tumbler Stop also numbered X39
88/091354	T50	ME 6772/52	Gate Stop Top - State Rise
88/091356	T219		Tumbler Post Mounted Gate Stop
88/091358	T53		Gate Stop Tumbler Large
88/091361	T233		Road Stop Cover 10" Rise R.H.
88/091362	T230	ME 6772/69	Road Stop 10" Rise
88/091366	T232		Road Stop Cover 10" Rise L.H.
88/091371	T101	MA 7077/5	Gate Crank Cap
88/091373	T31	MB 6584/13	Gate Wheel Standard, without Boss
88/091374	T31	MB 6584/13	Gate Wheel Standard, with Boss
88/091376	T21	MB 6720/4	Gate Roller Box Wheel
88/091379	T45?		Bearing
88/091384	T143		Stop Guide
88/091391	T144		Stop Guide
88/091393	T170		Wicket Gate Hinge Central Old Pattern
88/091395	T196		Road Stop Cover Left Hand
88/091401	T197		Road Stop Cover Right Hand
88/091402	T217*c	MD5706/42	Road Stop Cover Large R.H.
88/091403	T221		Gate Stop Tumbler Post Mounted
88/091408	T223		Gate Hinge
88/091409	T224		Gate Hinge Cap
88/091410	T227		Base For Post 2¼" Dia.
88/091419	T235		Road Stop Top 6 ½" Rise 1 in 24
88/091429	T239		Road Stop Top 6½
88/091439	T240		Road Stop Cover 6½" Rise R.H.
88/091443	T241		Road Stop Cover 6½" Rise L.H.
88/091445	T251		Crank Block
88/091448	T252		Cover Road Stop
88/091450	T255		Road Stop Cover 12" Rise Note When ordering Road Stop Tops please State Rise Lap and Gradient as there are a number of duplicate numbered patterns with different parameters

PADS No.	Drawing No.	Description Listed in Pads Order
88/091454 61	MB 6654/3	Bearing Gate Post Top Large New Pattern
88/091455 62		Lever Contact
88/091456 64		Bridge Track Circuit Indicator (Front Bearing)
88/091457 66		Base Plunger type Ringing Key
88/091458 67		Plunger Guide for Ringing Key
88/091458 79		Crank Swan Neck Contact Box
88/091461 T168		Wicket Gate Hinge R.H. Old Pattern
88/091762 V59		Annetts Lock Carrier see section B
88/091763 A90	MD 7484/4	Locking Frame side Left Hand Ground Frame Class 2
88/091765 A91	MD 7484/4	Locking Frame side Right Hand Ground Frame Class 2
88/091770 A93	MA 7436	Distance Piece Ground Frame Class 2
88/091771 A32	MA 6650/5	Distance Piece 2 Lever Wicket Detonator Frame
88/091780 A38	MB 7253	Tappet Plate 1 or 2 Lever Frame Ground Frame Class 2
88/091782 A92	MD 7484/7	Locking Frame Quadrant Ground Frame Class 2
88/091784 A23	ME 8359	Ground Frame Quadrants Stud locking, 5" or 5¼" Centre Class 6
88/091793 A94	MA 8997	Distance Ring Ground Frame Class 2 also 6A
88/091794 A22	ME 8559	Ground Frame Quadrants End Left hand
88/091795 A24		Ground Frame Quadrant End Right-hand
88/091807 G223	MB 6931	Bracket Signal Blocks 10¾" angle Iron 2½" Gap
88/091809 G224	MB 6932	Bracket Signal Blocks 10¾" angle Iron 3" Gap
88/091811 G191	MA 6750	Tubular Signal 5½" Blocks
88/091827 G171	MB 8215/1	Back Blinker Boss 12
88/091831 G220		Bracket Fixed Signal Arm Tubular Signal
88/091834 G228	MB 6292	Revolving Lamp Bracket
88/091834 G228	MB 6930/5	Revolving Lamp Bracket revised version
88/091837 G184		Combined Lamp and Stop Bracket
88/091843 G204	MB 6830	Top Strut Bracket 10¾" Bracket Signal
88/091844 G222	MB 6842	Bottom Strut Bracket 10¾" Bracket Signal
88/091845 G247	MB 6568	Strut Bracket Top 30' Angle
88/091846 G189	MB 5869	Currently not available
88/091848 G221	MB 7056	Bracket Signal Cap 10¾" dia. Bracket
88/091863 G227	MB 7226	Clip for Lamp Bracket, Revolving Type on Tubular signal
88/091868 G231		Lamp Bracket with Arm Stop U.Q.
88/091869 65		Cheek Bearing Collar S.P. N.P.
88/091883 G241		Duct Entry for 5½" Tubular Mast
88/091888 140		Battery Box Fastener (2 Parts)
88/091906 511		Cover Arm Gauge
88/091907 512		Gauge Signal Arm
88/091908 G177	MB 6899	Rod Guide No.1
88/091956 G208	MD 6858	Single Lever Plate for 5½" Tubular Mast
88/091957 G245		Lever Plate Double 5½" Mast
88/091959 G210	MD 6920	Single Lever Plate for 6½" Tubular Mast

PADS No.		Drawing No.	Description Listed in Pads Order
88/091960	G244		Lever Plate Double 6½" Mast
88/091982	G89		Lever Plate Single
88/091983	G90		Lever Plate Double
88/091984	G93	MD 9213	Lever Plate 3 Levers
88/092003	G158	MB 6884	C.O. Arm Boss 7" Centre
88/092005	G45	MB 8307	Boss Plate Round
88/092009	G170	MD 7067	Boss and Spectacle Plate Tubular Signal
88/092018	A9		Footblock Lever Frame
88/092027	A13		Tappet Plate 9 x 11 - 4"centres Lever Frame
88/092027	D62		Horizontal Crank Frame Single
88/092029	D63		Horizontal Crank Frame Double
88/092031	G206	MB 5076/44	Wire Crank Plate 1 Crank for 6½" Tubular Mast
88/092033	G207	MB 6882	Wire Crank Plate 2 Cranks for 6½" Tubular Mast
88/092035	G225	MD 7169	Double Crank Plate 10¾" dia. Bracket Signal
88/092037	G226		Triple Crank Plate 10¾"dia. Bracket Signal
88/092041	A82		Tappet Plate 5 x 2 - 4" Centre
88/092042	A83		Tappet Plate 5 x 3 - 4" centre
88/092043	A85		Tappet Plate
88/092044	A95CE	ME 7345/13	Footblock Quadrant Lever Frame 5 Bar Vertical Locking
88/092045	B21	MB 7005/5	Lever Crank Plate 3 Bar H T Frame
88/092051	F7*		Quadrant and Lever Independent Disc
88/092052	F41		Pedestal with Detector mount Single Disc
88/092066	F42		Pedestal Single Disc
88/092067	72		Adjusting Connection Locking 5/8"
88/092069	J4	MB 8410	Bearing Signal Selector
88/092074	F47		Spectacle Plate Independent Disc
88/092079	F63*		Pulley I. D. Single
88/092099	F72		Arm UQ I.D. Tubular
88/092116	G229	MB 6293/2	Revolving Lamp Bracket Table
88/092118	G179	MB 6891	Tubular Signal Post Top (Finial)
88/092123	G18*		Cradle Casting
88/092125	G252		Lever Balance Weight 7lb.
88/092126	G91	MB 8210/3	Weight, Dummy 12lbs
88/092127	G98	MB 8211/3	Weight 20lbs
88/092128	G96	MB 8212/3	Weight 30lbs
88/092129	G97	MB 8213/3	Weight 40lbs
88/092135	G28		Quadrant Sweep Casting L.H.
88/092136	G28		Quadrant Sweep Casting R.H.
88/092137	G43		Boss Plate 3'
88/092138	60	MB 6658/3	Bearing Gate Post Top
88/092139	G43NA		Boss Plate 4'
88/092140	G47	MB 7550	Bearing N.P. For Spindle
88/092142	G49		Signal Post Top (Finial)
88/092143	G58		Arm Stop Casting S.B
88/092146	G62		Guide For Rod Triple

PADS No.	Drawing No.	Description Listed in Pads Order
88/092147	G64	Guide For Rod Double
88/092148	G66	Guide For Rod Single
88/092149	G67	Guide For Rod Single
88/092151	G68	Guide For Rod Single
88/092152	G76	Boss For Blinker
88/092153	G91	Weight 50lbs Old Pattern
88/092154	G94	Lever Plate 4 Levers
88/092155	G123	Washer C.I.
88/092156	G143	Slip Arm Boss
88/092159	G157	Boss and Spectacle Plate 12"Centre
88/092160	G159	Arm Stop
88/092161	G173*	Lamp Bracket Clip
88/092162	G251	Lever Plate 5 Levers (Route Indicator)
88/092163	J7A*	Distance Piece 1 3/8
88/092164	J8	Staff/Token Picking Up Box Base Tubular Mast
88/092165	J9	Staff/Token Setting Down Horn Blocks Tubular Mast
88/092167	U9	Stove Front Bar
88/092168	U12	Door Knob
88/092169	U21	Fire Brick Right Hand
88/092173	U22	Fire Brick Back
88/092174	U23	Fire Brick Left Hand
88/092176	U24	Grating (marked X1)
88/092179	U33	Shelf Bracket 10 1/2" x 10 1/2"
88/092180	U36R	Ventilator Casting
88/092181	U41	MB 6856 Flag Bracket Stand
88/092183	U42	Flag Bracket Socket
88/092185	U48	Timber Box Standard
88/092191	U49	Brick Box Standard
88/092192	U62	Stage Bracket
88/092193	U66C	L.F. 2 Hole Adjusting Plate
88/092194	U71	Shoes Lever Frame 14" x 5"
88/092195	U74	S Plate – Temporarily withdrawn
88/092196	U75	Door Plate
88/092197	U76	T Plate - Temporarily withdrawn
88/092198	U79	Step Plate
88/092199	U83	Pipe Rail Standard
88/092200	U102	Range Fitting Fire Cover Plate – Stove U1
88/092201	U105	Range Fitting Oven Bottom – Stove U1
88/092202	U108	Range Fitting Cheeks Back – Stove U1
88/092203	U109	Range Fitting Cheek R.H. – Stove U1
88/092204	U110	Range Fitting Cheek L.H. – Stove U1
88/092211	U112	Range Fitting Grating – Stove U1
88/092212	U114	Range Fitting Ash Pan – Stove U1
88/092216	U117	Range Fitting Oven Door Hinge – Stove U1
88/092217	U118	Range Fitting Fire Door – Stove U1

PADS No.	Drawing No.	Description Listed in Pads Order
88/092218	U119	Range Fitting Front Fire Bars – Stove U1
88/092219	U123	Range Fitting Front – Stove U1
88/092222	U125	Range Fitting Tray – Stove U1 & U1A
88/092223	U131	Range Fitting Top Plate – Stove U1A
88/092227	U132	Range Fitting Side Right – Stove U1A
88/092228	U133	Range Fitting Side Left – Stove U1A
88/092229	U134	Range Fitting Back – Stove U1A
88/092230	U138	Range Fitting Oven Back Large – Stove U1A
88/092237	U140	Range Fitting Oven Door – Stove U1A
88/092243	U141	Range Fitting Oven Door Hinge – Stove U1A
88/092253	U142	Range Fitting Oven Door Latch – Stove U1A
88/092264	F64	MB 6407
88/092266	U144	Range Fitting Grating Frame – Stove U1A
88/092268	U146	Range Fitting Fire Door - – Stove U1A
88/092271	F68	MB 7221
88/092274	F71	MB 6325/2
88/092276	F65	MD 6157/24
88/092278	F70	Cap for Tubular I.D
88/092280	F75	MA 5530/29
88/092301	F62	MD 7058
88/092310	F69	MB 7045
88/092327	U147	Range Fitting Front – Stove U1A
88/092328	U148	Range Fitting Ash Pan – Stove U1A
88/092329	U151	Range Fitting Middle Plate – Stove U1A
88/092332	U152	Range Fitting Flue Plate – Stove U1A
88/092333	U153NA	Range Fitting Plinth – Stove U1A
88/092334	U156	Chimney Cowl – Cast rather than fabricated
88/092337	U189	MD 7752
88/092338	U191	MD 8612
88/092340	V3	Signal Box Stove Sleeve adapter (4" to 6")
88/092341	V5	Mounting Frame Spring Cushion?
88/092342	V91	Sash Roller Frame Part of U43
88/092343	V92	Portable Forge Weight
88/092344	V92	Portable Forge Wheels
88/092345	V95	MD 7551
88/092348	V131	Portable Forge Blast Pipe
		Lever Bearing for class 6 frame also Suits Class 2
		Ground Frame
88/092352	V189	5" Spectacle Ring see section G
88/092354	V196	Rocking Shaft Bracket see section P
88/092358	V203	Scotch Block GWR padlocked type also numbered 492A and N2703
88/092367	V204	Base for GWR Scotch Block
88/092368	V212	Boss Additional Weight for Some G43 - 4ft to make special arm or to convert to 5ft version
88/092381	V214	Spectacle Plate Additional Weight as G150
88/092399	X1	Signal Lever Plate 3 Levers
88/092401	X2	Front Spectacle Large Disk
88/092402	X3	As X2 only no provision for Spectacle Glass

PADS No.		Drawing No.	Description Listed in Pads Order
88/092407	X4*		Step Bracket 8
88/092411	X5*		Step Bracket 26
88/092419	X11	MB 7918	Auto-Clearance Bar Spring Cushion Bearing
88/092420	X16		Magazine Plate Token Instrument
88/092421	X19		Driving Arm Lever Plate
88/092422	X20		Front Intermediate Token Instrument
88/092423	X21		Back Intermediate Token Instrument
88/092425	266		Locking Frame Nib N.P. 5 Bar 4 1/8 "x 1 3/8
88/092430	275		Locking Frame Nib 1 3/4" x 1 3/8"
88/092434	279		Locking Frame Nib 9
88/092435	280		Locking Frame Nib 4" x 1 3/8"
88/092436	281		Locking Frame Nib R.H. L.H
88/092439	294	MA 6073/4A	Nut Wire Adjusting
88/092440	297L		L.H. Front Plate Old Style Block Instrument
88/092442	297R		R.H. Front Plate Old Style Block Instrument
88/092443	402		Locking Frame Nib 5 1/4" E
88/092444	403	MB 7532	Locking Frame Nib 5 1/4" F
88/092449	405C		Locking Frame Nib 4" VT
88/092453	A81		Tappet Plate 5 x 1 - 4" Centre
88/092454	A81		Tappet Plate 5 x 5 - 5" centre
88/092482	U66B	MD 6070/38	L.F. Truss Bracket
88/092484	B106	ME 6910	Currently NOT available Lever Cam Box n.p
88/092489	J7		Lever Collar 4" Centre (Reminder Collar)
88/092512	A1C	MD 837	Footblock Space Lever 4" Centre 3 Bar Vertical
88/092513	B15	MB 8081	Lever Cam Box 3 Bar VT 4" Centre Frame
88/092515	A7	MA.6873	Crossbar Holder Lever Frame
88/092522	B103	MA 6862	Tappet Joint
88/092523	201	MA 9108/19	Locking Frame Lug Joint 3
88/092526	B5	MB 6463/7	Clip Box Old and New Pattern Lever
88/092534	B8	MB7060	Universal Type Lever Badge
88/092545	B107	MB 7572	Cam Box Lid Lever Frame
88/092551	398	MB 7663	Locking Frame Nib 5 1/4" A
88/092552	400	MA 7529	Locking Frame Nib 5 1/4" C
88/092553	404	MB 7535	Locking Frame Nib 5 1/4" G
88/092554	405	MA 7527	Locking Frame Nib 5 1/4" H
88/092555	485		Locking Frame Nib N.P. 5 Bar Right Hand
88/092557	487	MA 7179	Locking Frame Nib N.P. 5 Bar Back Fixed
88/092558	488	MA 7181	Locking Frame Nib N.P. 5 Bar Ordinary Fixed
88/092559	489	MA 7183A	Locking Frame Nib N.P. 5 Bar Interlocking Fixed
88/092560	490	MA 7185A	Locking Frame Nib No.1 Ordinary
88/092561	491	MA 7187	Locking Frame Nib No. 2
88/092562	492	MA 7189A	Locking Frame Nib No.3 Interlocking Ordinary
88/092563	493	MA 7191	Locking Frame Nib No. 4
88/092564	494	MA 7193	Locking Frame Nib No. 5
88/092565	495	MA 7196	Locking Frame Nib No.6 Bottom thin
88/092566	496	MA 7198	Locking Frame Nib No.7 Top Fixed Thin

PADS No.		Drawing No.	Description Listed in Pads Order
88/092567	497	MA 7200	Locking Frame Nib No.8 Interlocking Conditional
88/092568	498	MA 7202	Locking Frame Nib No. 9
88/092571	274	MA 7495	Locking Frame Nib 3 Bar 2" x 3/8
88/092572	269	MA 7493	Locking Frame Nib 1 5/8" x 1 3/8"
88/092573	289		Locking Frame Nib L.H. 4" Centre 3 Bar H.T
88/092574	290		Locking Frame Nib R.H. 4" Centre 3 Bar H.T
88/092575	286		Locking Frame Nib 3 Bar VT 2" x 1 3/8
88/092576	285	MA 7519	Locking Frame Nib 3 Bar VT 2" x 1 3/8
88/092578	284	MA 7501	Locking Frame Nib 2 1/4" x 1 ?"
88/092581	268	MA 7491	Locking Frame Nib 2 1/2" x 1 3/8"
88/092582	277	MA 7515	Locking Frame Nib 2 3/4" x 1 3/8"
88/092583	278		Locking Frame Nib 2 3/4" x 1 3/8"
88/092584	287		Locking Frame Nib 3 Bar End V
88/092585	283	MA 7503	Locking Frame Nib 9 - 4" Centre 3 Bar HT Special
88/092586	288		Locking Frame Nib 4 1/2"
88/092646	U66D	MB 6945	L.F. 2 Hole Adjusting Plate 8 1/2" Centre for 5 bar 4" centre VT Frame
88/092654	U66A	MB 7558	Adjusting Plate One Hole
88/092663	A80	MD.7215	Tappet Plate 4 x 4 - 5 1/4" centre
88/092665	A84	MD 68988	Tappet Plate New pattern 4" Centre 5 Bar Vertical Locking
88/092670	A95		Footblock Quadrant Lever Frame 5 Bar Vertical Locking 1926 Standard Frame
88/092674	B105*		Lever Tail Shoe
88/092678	93	MA 6010/66	Lever Link Cam Box N.P. see 242
88/092688	V205	MA 7429	Tappet Plate Pipe Support see section A and U
88/092735	X12	MD 8076	Bends Stove Pipe
88/092736	U7		Soot Box
88/092737	U11	MB 7285	Soot Box Door
88/092740	U135		Range Fitting Cheek Back Large – Stove U1A
88/092741	U136		Range Fitting Cheek R.H. Large – Stove U1A
88/092742	U137		Range Fitting Cheek L.H. Large – Stove U1A
88/092743	U29	MD 7992	Roof Stove Pipe Collar
88/092744	U154	MB 7915	Range Fitting Damper – use with U11
88/092745	U143	MB 8017	Range Fitting Grating Bottom Large – Stove U1A
88/092746	U145		Range Fitting Fire Bars Front – Stove U1A
88/092750	U149		Range Fitting Fire Cover Plate – Stove U1A
88/092751	U150		Range Fitting Round Cover Plate – Stove U1 & U1A
88/092752	U139		Range Fitting Oven Bottom Large – Stove U1A
88/092753	U28	MB 6860/1	Roof Stove Pipe Sleeve 6"
88/092755	U190	MD 8611	Signal Box Stove Sleeve adapter (5" to 6")
88/092768	U80	MB 6022	Step Bracket
88/092789	V99	ME 8079	Forge Pipe Joint Connection
88/092791	V98		Forge Weights Large
88/092825	B112	MD 7082	Lever Tail Shoe with Lug

PADS No.		Drawing No.	Description Listed in Pads Order
88/092826	271	MA 7509	Locking Frame Nib 2" x 1 3/8"
88/092872	B24	MB 5982/19	Lock Box Annetts Lock
88/092874	B25	MB 5982/17	Lock Lid Annetts Lock
88/092876	B28	MB 5982/11	Drop Piece Annetts Lock
88/092878	235		Annetts Key formerly S 416
88/092886	422	MA 5982/13	Annetts Lock Ward Bottom
88/092887	421	MA 5982/15	Annetts Lock Ward Top
88/092888	418	MG 5988/1	Bolt Token Key Lock
88/092922	V221		Box, Token Key Lock
88/092924	V220		Lid, Token Key Lock
88/092926	V222		Cover, Keyhole Token Key Lock
88/092929	419A		Guide Token Key Pattern A
88/092930	419B		Guide Token Key Pattern B
88/092931	419C		Guide Token Key Pattern C
88/092932	419D		Guide Token Key Pattern D
88/092974	V197	MB 6001/1a	Rocking Shaft Sleeve
88/092979	P12	MB 7041	Parallel Bar Inside Stop
88/092979	P31		Parallel Bar Bull Head Check Rail Bracket
88/093002	P100	BRS-SM 303	F.P.L Plunger Base
88/093003	K1	MB 6020/2	Crank Pedestal Cheek 4" Centres
88/093005	K3	MB 6020/3	Crank Pedestal 4" Centre
88/093005	P102	BRS-SM 303	F.P.L Slide Cover
88/093006	K31		Crank Plate 4" Centre, H.S.
88/093007	K41	MD 7263B	Crank Mounting Plate 4x6
88/093008	K42	MD 7264A	Crank Mounting Plate 3x6
88/093008	P103	BRS-SM 303	F.P.L Plunger Cover
88/093009	L11		Compensator Plate New Pattern
88/093010	M6		Lamp Stand
88/093011	P151*		F.P.L Plunger Base New Pattern
88/093013	P101	BRS-SM 303	F.P.L Detector Slide
88/093014	S7A	MD 3783A	Travelling Roller Sides
88/093017	E74		BR Standard Channel Rodding Wheel
88/093056	S27	MD 6116/4	Saddle Brackets
88/093057	S28	MD 6116/3	Saddle Brackets for Hinges
88/093058	S21	MD 6797/3	Roller Box Solid Rodding New Pattern
88/093060	300	MB5920/1&2	Connection Adjusting 1" x 7/8
88/093115	S9A	MA 3783/6	Travelling Roller Wheels Solid Rodding
88/093116	S22	MA 6797/4	Roller Box Wheel Solid Rodding
88/093117	S49		Travelling Roller Wheel Channel Rodding
88/093522	C28	MD 6912	Standard Wire Adjuster
88/093524	C35	MB 6971	Handle Hex. Head. Spindle Wire Adjuster
88/093537	D35	BRS-SM-108A	Guides Vertical Wheels and Frames
88/093549	D31		Pulley Frame Flat 14" Single
88/093550	D32	M 5800	Pulley Frame Flat 14" Double
88/093557	C12	MD 6415	Pulley Wheel 9in Wire Adjuster
88/093559	D28	MD 7930/1	Pulley Frame Vertical Old Pattern

PADS No.		Drawing No.	Description Listed in Pads Order
88/093561	D17	MB 6430	Pulley Wheel 10" Flat W.R. Pattern
88/093562	D20	MB 6902	Pulley Frame Flat 8" or 10" Single
88/093565	D21	MB 6903	Pulley Frame Flat 8" or 10" Double
88/093566	D22	MD 6852	Pulley Frame Flat 8" or 10" Triple
88/093567	D25		Pulley Wheel 10"
88/093568	D26	MD 7107	Pulley Frame Vertical
88/093569	D28		Pulley Wheel 10" Lightweight
88/093570	D30		Pulley Wheel 10" BR Pattern
88/093571	D33		Pulley Frame Flat 14" Triple
88/093573	D37	MB.6020/34A	Pulley Frame Flat 14" Double
88/093576	K20		Crank Base Low
88/093578	L20		Compensator Base
88/093579	K30		Crank Plate L.S.
88/093605	K43	BRS/SM 216	Cap Centre Pin Crank & Compensator
88/093615	K36		Dust Cover
88/093792	E63		Bracket Detonator Placer
88/093793	E64		Cover Detonator Placer
88/093794	E73	MB 7152	Link Detonator Placer
88/093795	E77	MA 8428/16	Detector Blade Double Dummy BR
88/093795	103	MB 7161A	Detonator Layer Carrier
88/093796	674	MB 7160	Detonator Holder for Placer also numbered 672-88/093802
88/093799	E75		Spacer Detector N.P
88/093800	V79		Detonator Placer 3 Shot Cover
88/093801	102	MB 7826/4	Carrier Detonator Placer
88/093802	672		Holder Detonator Placer Single and 3 Shot
88/093809	V77		Detonator Placer 3 Shot
88/093810	V80	MB 6650/10	Clip Box Detonator Placer Lever Frame see also section B and T
88/093825	Q8		F.B. Bracket
88/094712	376D		Flat Bar 8" x 1" x 1/4"
88/094713	376A		Flat Bar 8" x 1 1/4" x 1/4"
88/094714	376B		Flat Bar 11" x 2 1/8" x 1/2"
88/094715	368		Strip 17" x 1 1/2" x 1/2"
88/094716	369		Strip 12" x 1 5/8" x 7/8"
88/094717	373		Strip 13 3/8" x 2 1/8" x 7/8"
88/094718	371		Strip 20" x 1 7/16" x 5/8"
88/094720	43		Round 12" x 1 1/4"
88/094723	240		Round 7"x 2 1/2" Round 7"x 2 1/2" Round 7"x 2 1/2"
88/094725	206		Butterfly Nut
88/094758	688		Lamp Hinge Bottom
88/094763	1031	MB 8498	Mounting Screen T Lamp Supersedes 1030 formerly S250
88/094764	1032		Mounting Screen T Lamp Supersedes 1029 formerly
88/094895	G172	MD 7231	Spindle Bearing Tubular Signal
88/095634	356		Stop Square 1 1/4"

PADS No.	Drawing No.	Description Listed in Pads Order
88/098894	420	Ward Token Key Lock N.P.
88/930012	P152	F.P.L Bolt Lock Cover New Pattern

**PADS /
N.R.S** **BR(W)
No.**

Drawing No. **Description**

BR STANDARD PARTS

88/074589	E60	BRS-SM101.A	Box Detector New Pattern
86/087653	*	BRS-SM 103/12	Signal wire pulley- galvanised Minimum Order Quantity will apply
86/087910	*	BRS-SM 103/4	Signal wire pulley- block 4 way galvanised - no pulleys Minimum Order Quantity will apply
88/093540	D30	BRS-SM 107	Pulley Wheel 10" BR Pattern
88/085333	D35	BRS-SM 108.A	Guides Vertical Wheels and Frames
88/085335	D28	BRS-SM 110	Pulley Wheel 10" Lightweight
86/064700	*	BRS-SM 202/1	Frame for Point Roller Minimum Order Quantity may apply
86/064710	*	BRS-SM 202/2	Roller Minimum Order Quantity may apply
86/064720	*	BRS-SM 202/3	Ferrule Minimum Order Quantity may apply
88/093576	K20	BRS-SM 204	Crank Base Low
88/093578	L20	BRS-SM 205	Compensator Base
88/093605	K43	BRS-SM 216	Cap Centre Pin Crank & Compensator
88/093002	P100	BRS-SM 303	F.P.L Plunger Base
88/093013	P101	BRS-SM 303	F.P.L Detector Slide
88/093005	P102	BRS-SM 303	F.P.L Slide Cover
88/093008	P103	BRS-SM 303	F.P.L Plunger Cover
86/075352		BRS-SM 315/	Plunger for Mk II F.P.L fabrication
86/075351	P160	BRS-SM 315/1	F.P.L Plunger Base Mk II
86/075151	P161	BRS-SM 315/2	F.P.L Detector Slide Mk II
86/075355	P162	BRS-SM 315/4	Cover For Mk II see Aluminium Section Cover
86/068852	X115	BRS-SM 452/5	Lever Clip Box Ground Frame